

Automatic adjustment for Daylight Saving Time

Notes: This doesn't work on ESI systems manufactured before February, 2003 — specifically, IP 200, IP 40, IVX 128 Plus, IVX 128, IVX 20 Plus, IVX 20, and [original] IVX.

If you don't know which ESI system you have, consult your ESI Reseller.

This feature, when enabled, causes the phone system's real-time clock to adjust itself automatically for Daylight Saving Time. The options are *AUTO* [enabled] and *DISABLE* (the latter is best for counties or states that don't observe DST).

To set this feature:

1. On any ESI phone within the system, press **PROG/HELP**.

Note: If using an ESI Feature Phone that has separate **PROGRAM** and **HELP** keys, press **PROGRAM**.

The normal **station** programming menu prompt will begin to play.

2. Stop the prompt by pressing **HOLD** (or, on an older ESI phone, **PARK**).
3. Enter the **Administrator password** and then press **#**.

Note: If this doesn't admit you to Administrator-level programming (the phone display should show *ADMINISTRATOR*), contact your ESI Reseller for assistance.

4. Access **Function 142** by pressing **1 4 2** and then **#**.
5. The phone display will show *AUTO TIME SET*, and either *ENABLED* or *DISABLED*. If necessary, use the phone's **scroll keys** to toggle between the two settings. We recommend the *ENABLED* setting. When the display shows the setting you want, press **#**.
6. The phone display will now show *DAYLIGHT SAVING*, and either *AUTO* or *DISABLED*. If necessary, use the phone's **scroll keys** to toggle between the two settings.
If you want your phone system to adjust its clock setting automatically whenever your time changes between Daylight Saving Time and Standard Time (either direction), select *AUTO*. If you live in an area which doesn't observe Daylight Saving Time, select *DISABLED*.
When the display shows the setting you want, press **# #** and hang up.